

The SMART START IN-HOM™ (“IN-HOM”) is a breath-alcohol device with a photo identification feature that requires the user to take a breath test during specified “test windows.” The device will indicate to the user when a test is required with the use of an LCD located on top of the IN-HOM unit. The unit will also beep during the required “test windows”. The same LCD is used to inform the user of the breath sample result. An instruction label is located on the left-hand side of the unit. The IN-HOM unit consists of four parts: the IN-HOM device, a mouthpiece, a power supply with A/C cord, and a transport case.

SETTING UP THE IN-HOM UNIT:

1. Make sure the IN-HOM unit is sitting on a flat, sturdy surface.
2. Connect the power supply cord to the IN-HOM unit and plug it into an electrical outlet. The unit will activate and the LCD will display **WAIT ####**, and then **BLOW**. Remember to leave the IN-HOM unit connected to power; not doing so may result in a missed test. The power may be removed if you plan to transport the device.
3. Place the mouthpiece in the nozzle found on top of the IN-HOM unit.

HOW TO TAKE A TEST:

1. Make sure the LCD displays the word **BLOW**. *At this time, drink WATER to eliminate any breath contaminants.*
2. Take a deep breath and blow steadily into the mouthpiece of the unit for approximately 3-4 seconds. During the test, the LCD will display the word **TEST**.
3. Keep blowing into the mouthpiece until the unit clicks and the sound of the beep changes to a higher tone to let you know when to stop (approximately 4 seconds).
4. After testing the LCD will display **ABORT** or **ANALYZING**.

ABORT	Test is not complete, wait for the unit to display BLOW and take additional tests until the result is PASS
ANALYZING	The unit is processing the breath sample followed by a result
• PASS	Test is complete
• WARN	Test is not complete, wait for the unit to display BLOW and take additional tests until the result is PASS
• FAIL	Test is not complete, wait for the unit to display BLOW and take additional tests until the result is PASS
• VIOL	Test is not complete, wait for the unit to display BLOW and take additional tests until the result is PASS

REQUIRED “TEST WINDOWS”

You must provide at least one sample with a “**PASS**” reading during this period. If you miss a “test window,” a **Violation** will be reported. Taking a test after the “test window” **WILL NOT** reverse this, however the unit will allow a test.

When the IN-HOM unit reaches a scheduled “test window”, the unit will beep, LED 2 will flash green, and the LCD will display “**BLOW**” along with a timer indicating how much time you have to take a test. A test **MUST** be taken during this time. As the “test window” nears the end of the allotted time, **THE UNIT WILL BEEP MORE FREQUENTLY**. You can voluntarily take a test outside of a “test window” as long as the device displays “**BLOW**”. ***Be sure to drink WATER prior to each and every test.***

SERVICE LOCKOUT

A **service lockout** is indicated by an LCD display of “**LOCKOUT SRVC**”. Before completely locking out, the LCD will display “**SvcLock ## hr**”. This is the number of hours remaining before the device locks out due to missing your service date. Once the grace period time expires, you will not be able to take a test and are required to call your service provider for further instructions on servicing your unit. **DO NOT IGNORE THE SERVICE WARNING** grace period.

VIOLATION LOCKOUT

A **violation lockout** is indicated by an LCD display of “**LOCKOUT VIOL**”. Before completely locking out, the LCD will display “**ViolLck ## hr**”. This is the number of hours remaining before the device locks out due to violations. Once the grace period time expires, you will not be able to take a test and are required to call your service provider for further instructions on servicing your unit. A violation is caused by a **HIGH LEVEL** breath failure **OR** by missing a test. **DO NOT IGNORE THE LOCKOUT WARNING** grace period.

SMART START IN-HOM™

Quick Reference Information

AFTER HOURS SERVICE

If you need service after normal business hours, call Smart Start toll free at **1-800-880-3394**. Our answering system will direct you to the appropriate department; please follow the directions. **If you leave a message, be sure to include your full name, date of birth, area code, phone number and mention that you are an IN-HOM client so we can return your call.**

IN-HOM SERVICE

You will be instructed when to bring the IN-HOM device for service. The device must always be carried in the transport case. *Be sure to make note of your service appointment date.*

IN-HOM LCD STATUS INFORMATION

LCD DISPLAYS	DESCRIPTION
WAIT ##	The unit is preparing for a breath test.
BLOW	The unit is ready to accept a breath test.
TEST	The unit is accepting the test.
SvcLock ## hr	A reminder of the number of hours remaining before the unit goes into lockout due to missing your service appointment.
VioLck ## hr	A reminder of the number of hours remaining before the unit goes into lockout due to violations.
LOCKOUT VIOL	The device is in lockout due to violations. You will not be able to take a test and are required to call your service provider for further instructions on servicing your unit.
LOCKOUT SRVC	The device is in lockout due to missing your service date. You are not able to take a test and are required to call your service provider for further instructions on servicing your unit.
APPT MM/DD	A reminder, your appointment date is approaching. Starts flashing 5 days before your appointment date
MISSED TEST	A test with the result of "PASS" was not provided during a "test window".

- *You must drink WATER prior to each and every breath test. This will eliminate breath contaminants. Remember; always take a DEEP BREATH immediately before taking a test.*
- Do not use a breath freshening agent or any contaminants before taking a test; most of these agents contain a high level of alcohol.
- Once the device begins asking for a test, be sure to take the test; **NOT doing so will result in a VIOLATION.**
- Place the device where you can see the LCD and hear the BEEP TONES. If a test is requested and you are in a loud environment, you may not hear the beeping sound from the unit.
- Do not place the IN-HOM unit on the floor, around extreme temperatures, where it is prone to damage, or where you can't see it or hear it. Also, do not expose the unit to moisture from liquids. **You are responsible for damages due to negligence or abuse of the device.**
- Your picture is being taken and viewed. You are required to dress appropriately at all times.

If your IN-HOM unit locks out or is not operating properly, please call Smart Start at 1-800-880-3394 for assistance. We may ask you to bring the unit to the nearest location for service.